

LED INDICATORS

This document describes the behavior of the RX LED in the HiPer+ receiver, which is equipped with FH915 or FH2400 modem.

LED Status	Explanation
No light	Modem is turned off
Green flashes	Modem is in receiver mode
Solid green (non-blinking)	Radio Link established. Modem is ready to receive data
Solid green + red blinks	Modem is receiving data
Solid red	Modem is in transmitter mode
Red flashes	A fault condition has been detected. Check the condition of both the cable running from the antenna to your radio modem and connectors to make sure they are not loose or damaged. Also make sure that there are no conducting objects near the antenna location.
Red blinks + green blinks	Modem is in command mode