

tune your ride

The Quadcarver Pro performs even better if you adjust it to your particular riding style. Enhance your carving experience with these few easy steps:

step 1



- 1.) Remove the riser
- 2.) Open both locking nuts (pic 1)
- 3.) Attention: Just opening the locking nuts does NOT adjust the steering.

step 2



- 4.) Loosen the index clamp pic 2
- 5.) Tighten the lower locking nut until your steering assembly has the desired resistance (turn the front truck)
- 6.) Secure the upper locking nut.
- 7.) Close the index clamp (Att: Do not over tighten the index clamp, only tighten until the gap closes)
- 8.) Mount the riser accordingly to the assembly instructions.

step 3



- 1.) Use the provided Allen wrench and turn the screw counter clockwise until the hanger moves freely. Once you can feel the free play, stop and re-tighten until the hanger free play goes away and the hanger centers. The truck is now set at "zero preload/zero free play".
- 2.) Continue to tighten by turning the screw clockwise 1-3 turns for lighter settings and up to 6 full turns for heavier riders and higher speed stability.
- 3.) Feel free to try different settings. However, it is your responsibility to adjust the spring preload for your body weight (70 to 250lbs) and riding style.

quadcarver™

www.quadcarver.com
e: info@quadcarver.com

800.727.0331